



## COTTAGE CRAFT SPIRALS

### PARISIENNE FIXING INSTRUCTIONS

Fix the base plate to the floor in the desired position. (see separate sheet for base plate fixing instructions).

**The Parisienne design is always fitted with the base plate surface mounted and there is no need to adjust the bottom tread.**

The bottom tread is identified by a smaller countersunk hole at the front of the tread to which the solid spacer is fitted.

ONLY if your Parisienne spiral has timber treads and you are building your own landing plate you will find a tread which has a square back edge and this is the final tread which is connected to your landing.

Locate the pole onto the base plate and slide the treads down ENSURING the bottom tread is first.

Place the balusters with the long threaded rod through the front hole of each tread, with a spacer between this tread and the tread below. The threaded rod should project through the back hole of the previous tread, tighten with a 12mm nut so that it is finger tight.

The final baluster/newel post must pass through the landing plate and the back hole of the final tread.

Place the handrail on top of the balusters and carefully screw the machine screws supplied into the top of the balusters ensuring the thread does not cross. If you have any additional balusters on each tread fit these now.

Starting from the top spanner tighten the nuts ensuring that the balusters stand straight and that the spiral does its full rotation.

Trim the excess threaded rod below the nuts where necessary.

Weld the handrail sections together. Fill out the countersunk holes in the handrail with "Plastic Padding" or similar. Smooth down and paint. The finial ball is for the top of the centre column and is tapped in tight.